

1. After the support leg assembly.
2. Ensure correct position of the support leg axis; photos 01 and 02

**Bild 01**



**Bild 02**



3. Ensure correct support leg position, indicating arrow is on the bottom side; photo 03

Bild 03



4. Put upper support leg cover in; photo 04

Bild 04



5. Put the positioned support leg in and pay attention to the correct position (!); photo 05 and 06

Bild 05



Bild 06



- Put lower support leg cover in, add latch to the support leg cover, screw cover and press latch together by hand (both latches must be engaged), photo 08



- Place the repaired seat on a table, let the support leg dangle to the bottom. The orange coloured indication arrow must be visible from the front. When turning the turning sleeve in the direction of the arrow the support leg must slip down on its own, and it must be easy (!) to slide it upwards again by hand.

If you have any further questions, please feel free to contact us.

Mit freundlichen Grüßen aus Ulm  
With kind regards from Germany

**Dietmar Wenzel**  
QM/VDA 6.1-Auditor  
Qualitätssicherung

**BRITAX RÖMER**  
**Kindersicherheit GmbH**  
Blaubeurer Straße 71  
D-89077 Ulm

**t** +49 (0) 731 9345-142  
**f** +49 (0) 731 9345-216  
**e** [dietmar.wenzel@de.britaxeurope.com](mailto:dietmar.wenzel@de.britaxeurope.com)

[www.britax-roemer.de](http://www.britax-roemer.de)  
[www.roemer.eu](http://www.roemer.eu)